


TP528



Ningbo Tooky Toy Co., Ltd.
Ningbo Tobby Creativity Technology Co., Ltd.

Tel: +86-574-5583-7721

Email: web@tookytoy.com

Add: Building C4, No 11 1000 Lane Yunshan Road, National
High-Tech Zone, Ningbo 315040, China

www.tookytoy.com

 **WARNING:**
CHOKING HAZARD - Small parts.
Not for children under 3 years. Adult assembly required.





NOTE : Please read instructions before assembly



NOTE

Be smart-sort your parts!



Be sure you have all required parts **BEFORE** beginning assembly!



Please use a manual screwdriver for assembly or set the electric screwdriver to the **MINIMUM TORQUE** to avoid damaging the product. If the minimum torque is not sufficient to turn the screws, gradually increase the torque as needed.



**DO NOT FULLY TIGHTEN SCREWS UNTIL
ALL PANELS ARE CONNECTED.**



To complete assembly, use a hand-held screwdriver to fully tighten all screws until they're snug.


DO NOT OVER-TIGHTEN!

Over-tightening will cause the product to crack!


- (EN) Warning!** Choking hazard - Small parts. Not suitable for children under 3 years. Adult assembly required.
- (DE) Achtung!** Erstickungsgefahr - Kleine Teile. Nicht für Kinder unter drei Jahren geeignet. moins de trois ans. Der Zusammenbau ist durch einen Erwachsenen vorzunehmen.
- (FR) Attention!** Danger d'étouffement - Petits éléments. Ne convient pas aux enfants de moins de trois ans. Assemblage par un adulte requis.
- (ES) Advertencia!** Peligro de atragantamiento - Partes pequeñas. No conviene para niños menores de tres años. Se requiere ensamblaje por un adulto.
- (IT) Avvertenza!** Rischio di soffocamento - Piccole parti. Non adatto a bambini di età inferiore a 3 anni. Richiesto assemblaggio da parte di un adulto.
- (NL) Waarschuwing!** Verstikkingsgevaar - Kleine onderdelen. Niet geschikt voor kinderen jonger dan drie jaar. Te monteren door een volwassene.
- (PT) Atenção!** Risco de asfixia - Pequenas partes. Contra-indicado para crianças com menos de 3 anos. Necessária montagem por um adulto.
- (GR) Προειδοποίηση!** Κίνδυνος πνιγμού - Μικρά μέρη. Δεν είναι κατάλληλο για παιδιά κάτω των τριών ετών. Απαιτείται συναρμολόγηση από ενήλικα.
- (JA) 警告!** 窒息の危険-小さな部品の誤飲・窒息の危険がありますので、3歳未満のお子様には絶対に与えないでください。組み立ては大人の方が行ってください。

1. The toy requires 3 × 1.5V AAA (LR03) batteries. Make sure the power switch is turned off before use. Locate the battery compartment (see Step.B) and open the cover (the battery compartment cover must be opened and closed by an adult using a screwdriver). Insert the batteries correctly according to the polarity markings (+/-). Remove used batteries and dispose of them properly. Reattach the cover and ensure the screw is securely tightened.
2. Do not attempt to recharge non-rechargeable batteries.
3. Rechargeable batteries should be charged under adult supervision.
4. Do not mix different types of batteries. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
5. Insert the batteries with the correct polarity (+/-).
6. Remove exhausted batteries from the toy.
7. Do not short-circuit the supply terminals.
8. The instruction must be retained since it contains important information.


CONTENTS



1 X 1pc




2 X 1pc



M4X30mm


3 X 2pcs


ACCESSORIES




1pc each

A



B

AAA (LR03) batteries (not included)

**C**